

Energy Saver User Settings



I am too warm....

If you are feeling too warm, use the temperature setting button to enter a lower setting

The Energy Saver will take you through the settings 1 to 7 if you hold the button down

Number 1 is the lowest temperature setting and 7 is the highest

I am too Cold...

If you are feeling too cold, use the temperature setting button to enter a higher setting

The Energy Saver will take you through the settings 1 to 7 if you hold the button down

Number 1 is the lowest temperature setting and 7 is the highest



I need more hot water....

If you need a lot of hot water pressing the boost button will give your central heating system a one hour boost to provide the extra hot water required for baths /water /heating etc.